

“DRV830x-HC-C2-KIT” How to Run Guide

Version 1.0 August 2011 - TIDU396

C2000 Systems and Applications Team

This Guide explains the steps needed to run the DRV830x-HC-C2-KIT with the software supplied through controlSUITE. This guide pertains to either the DRV8301-HC-EVM or the DRV8302-HC-EVM. The software is located at:

`controlSUITE\development_kits\DRV830x-HC-C2-KITv*`

The following projects are currently available for the kit:

- Fixed/Floating point projects based on Piccolo (TMS320F2803x or TMS320F2806x, using v3.1 DMCLib)

- PM_Sensorless: Sensorless Field Oriented Control of Permanent Magnet Motor
- BLDC_Int: Sensorless Trapezoidal Control of BLDC Motors based on BEMF Integration

The document assumes the user has read the Kit's Hardware Reference Guide and understood all the safety measures that need to be taken. The guide is found under

`controlSUITE\development_kits\DRV830x-HC-C2-KITv*\~Docs\`

WARNING



This EVM is meant to be operated in a lab environment only and is not considered by TI to be a finished end-product fit for general consumer use.

This EVM must be used only by qualified engineers and technicians familiar with risks associated with handling high voltage electrical and mechanical components, systems and subsystems.

This equipment operates at voltages and currents that can result in electrical shock, fire hazard and/or personal injury if not properly handled or applied. Equipment must be used with necessary caution and appropriate safeguards must be employed to avoid personal injury or property damage.

It is the user's responsibility to confirm that the voltages are identified and understood, prior to energizing the board and or simulation. When energized, the EVM or components connected to the EVM should not be touched.

Hardware Configuration

To experiment with digital motor control the following hardware components are needed:

- DRV830x-HC-EVM
- TMS320F28035 controlCARD;
- PMSM or BLDC Motor
- PC with Code Composer Studio (CCSv4) installed
- Additional instruments such as oscilloscope, digital multi-meter, current sensing probe and function generator.
- A high voltage DC power supply (Up to 60V DC)

The experimental setup and connection are illustrated in the following section. Refer to the Hardware Guide and DRV830x-HC-EVM schematic file for detailed configuration of each component and connection of the system in detail.

Note: Keep all the power supplies to zero unless directed to energize.

There are two main power domains on the DRV830x-HC-EVM platform:

- 1) **Controller Power Domain** which provides the 5V and 3.3V for the microcontroller, the logic and the sensing circuit present on the board.
- 2) **DC Bus Power** is the high voltage line that provides the voltage to the DRV830x chip to generate the power to the motor. The DC Bus is provided by an external DC power supply connected to the PVDD and GND terminals. (Max 60V DC)

Motor Control Experiment HW Setup Instructions

Unpack the DIMM style controlCARD and verify that the DIP switch settings match Figure 1.




Figure 1 controlCARD DIP Switch Settings

1. Place the controlCARD in the connector slot of J1. Push vertically down using even pressure from both ends of the card until the clips snap and lock. (to remove the card simply spread open the retaining clip with thumbs)
2. Connect a USB cable to J1 on the controlCARD. This will enable isolated JTAG emulation to the C2000 device. LD4 on the controlCARD should turn on.
3. Connect a 8-60V DC power supply to the PVDD and GND terminals of the DRV830x-HC-EVM. Now LED1 and LED3 should turn on. Notice the control card LED would light up as well indicating the control card is receiving power from the board.
4. Note that the motor should be connected to the OUT A, OUT B and OUT C terminals after you finish with the first incremental build step.




Figure 2 Hardware Setup for PM_Sensorless Experiment




Figure 3 Hardware Setup for BLDC_Sensored and BLDC_Sensorless Experiments



WARNING: DC bus Capacitors would remain charged for a long time after the supply is disconnected. Use caution!

Software Setup for DRV8301-HC-C2-KIT Projects

Installing Code Composer and controlSUITE

1. If not already installed, please install Code Composer v4.x from the DVD included with the kit.
2. Go to <http://www.ti.com/controlsuite> and run the controlSUITE installer. Select to install the “DRV830x-HC-C2-KIT” software and allow the installer to also download all automatically checked software.

Setup Code Composer Studio to Work with the DRV830x-HC-C2-KIT

3. Open “Code Composer Studio v4”.
4. Once Code Composer Studio opens, the workspace launcher may appear that would ask to select a workspace location,: (please note workspace is a location on the hard drive where all the user settings for the IDE i.e. which projects are open, what configuration is selected etc. are saved, this can be anywhere on the disk, the location mentioned below is just for reference. Also note that if this is not your first-time running Code Composer this dialog may not appear)
 - Click the “Browse...” button
 - Create the path below by making new folders as necessary.
 - “C:\Documents and Settings\My Documents\CCSv4_workspaces\DRV830x-HC-EVM_workspace”
 - Uncheck the box that says “Use this as the default and do not ask again”.
 - Click “OK”




Figure 4 Workspace Launcher

5. Next we will configure Code Composer to know which MCU it will be connecting to. Click “Target -> New Target Configuration...”. Name the new configuration xds100-f28035.ccxml or any other name depending on the target device. Make sure that the “Use shared location” checkbox is checked and then click Finish.




Figure 5 Creating a target configuration

6. This should open up a new tab as seen in Figure 6. Select and enter the options as shown:
 - Connection – Texas Instruments XDS100v1 USB Emulator
 - Device – TMS320F28035
 - Click Save
 - Close the xds100-f28035.ccxml tab




Figure 6 Configuring a new target

7. Assuming this is your first time using Code Composer, the configuration is now set as the default target configuration for Code Composer. Please check this by going to “View->Target Configurations”. In the “User Defined” section, right-click on the xds100-F28035.ccxml file and select “Set as Default”. This tab also allows you to reuse existing target configurations and link them to specific projects.
8. Add all the motor control projects into your current workspace by clicking “Project->Import Existing CCS/CCE Eclipse Project”.
 - Select the root directory of the DRV830x-HC-C2-KIT. This will be: “controlSUITE\development_kits\DRV830x-HC-C2-KITv*\”




Figure 7 Adding all DRV830x-HC-C2-KIT projects to your workspace

- Click Finish, this would copy all the projects relevant for the kit into the workspace. If you want only a particular project to be copied uncheck the box next to the other project names.

Configuring a Project

- Expand the file structure of the project you would like to run from the C/C++ Projects tab. Right-click on this project's name and select "Set as Active Project".
- Assuming this is your first time using Code Composer, the xds100-F28035 should have been set as the default target configuration. Do verify this by viewing the xds100-f28035.ccxml file in the expanded project structure and a [Active/Default] written next to it. By going to "View->Target Configurations" you may edit existing target configurations or change the default or active configuration. You can also link a target configuration to a project in the workspace by right clicking on the Target configuration name and selecting Link to Project.
- Each project has multiple build configurations to support different target MCUs or different DRV83xx base boards. You will need to select the build configuration that matches your hardware setup. As an example Figure 8 shows selection of the DRV8301-HC-EVM with a F2803x MCU. Right-click on an individual project and select Active Build Configuration-> DRV8301_F2803x_RAM configuration.




Figure 8 Selecting the DRV8301_F2803x_RAM configuration

Build and Load the Project

- The TI motor control software is provided with incremental builds where different components / macro blocks of the system are pieced together one by one to form the entire system. This helps in step by step debug and understanding of the system. From the C/C++ Project tab open the file [Project-Name]-Settings.h and make sure that BUILDLEVEL is set to LEVEL1 and save this file. After we test build 1, this variable will need to be redefined to move on to build 2, and so on until all builds are complete.

13. Open and inspect [Project-Name] -DevInit_F2803x.c by double clicking on the filename in the project window. Confirm that GPIO00 to GPIO05 are configured to be PWM outputs.
14. Open the [Project-Name].c file and go to the function MainISR(). Locate the following piece of code in incremental build 1 and confirm that the Datalog buffers are pointing to the right variables. These Datalog buffers are large arrays that contain value-triggered data that can then be displayed to a graph. Note that in other incremental builds different variables may be put into this buffer to be graphed. Following is an example where the datalog are pointed to the PID module.

```
DlogCh1 = (int16) _IQtoIQ15(pid1_i.Ref);  
DlogCh2 = (int16) _IQtoIQ15(pid1_i.Fdb);  
DlogCh3 = (int16) _IQtoIQ15(pid2_i.Ref);  
DlogCh4 = (int16) _IQtoIQ15(pid2_i.Fdb);
```

15. Now Right Click on the Project Name and click on “Rebuild Project” and watch the Console window. Any errors in the project will be displayed in the Console window.
16. On successful completion of the build click the  “Debug” button, located in the top-left side of the screen. The IDE will now automatically connect to the target, load the output file into the device and change to the Debug perspective.
17. Click “Tools->Debugger Options->Generic Debugger Options”. You can enable the debugger to reset the processor each time it reloads program by checking “Reset the target on program load or restart” and click “Remember My Settings” to make this setting permanent.
18. Now click on the “Enable silicon real-time mode” button  and “Enable polite real-time mode” button . This will allow the user to edit and view variables in real-time. Do not reset the CPU without disabling these realtime options!
19. A message box *may* appear. If so, select YES to enable debug events. This will set bit 1 (DGBM bit) of status register 1 (ST1) to a “0”. The DGBM is the debug enable mask bit. When the DGBM bit is set to “0”, memory and register values can be passed to the host processor for updating the debugger windows.


Setup Watch Window & Graphs

Click: View → Watch on the menu bar to open a *watch window* to view the variables being used in the project. Add variables to the watch window as shown below. By right-clicking on the variable it is possible to change the number format of the variable. Refer to the project specific document to know what variables need to be added to the watch window. You can select the appropriate Q format for the variable you want to watch. Figure 9 below shows a typical watch window.

Within each project folder is a CCS Java Script file that can automatically populate a watch window with some default variables. Select View->Scripting Console to open the Java Scripting Console. Next, in the Scripting Console window, click the open folder and browse to the project folder.

controlSUITE\development_kits\DRV830x-HC-C2-KITv*\<project directory>

Select the AddWatchWindowVars_F280xx.js file that corresponds to your target MCU.



Name	Value	Format	Address	Type
(X)= EnableFlag	0	Natural	0x00009B49@Data	unsigned int
(X)= lsw	0	Natural	0x00009B46@Data	unsigned int
(X)= IdRef	0.0	Q-Value(24)	0x00009B62@Data	long
(X)= IqRef	0.04999995232	Q-Value(24)	0x00009B60@Data	long
(X)= SpeedRef	0.3000000119	Q-Value(24)	0x00009B66@Data	long
(X)= pid1_spd.Kp	1.299999952	Q-Value(24)	0x00009CC6@Data	long
(X)= pid1_spd.Ki	0.01999998093	Q-Value(24)	0x00009CD8@Data	long
(X)= dlog_prescalar	1	Natural	0x00009C5F@Data	int
(X)= IsrTicker	0	Natural	0x00009B70@Data	unsigned long
(X)= clarke1.As	0	Q-Value(24)	0x00009B90@Data	long
(X)= clarke1.Bs	0	Q-Value(24)	0x00009B92@Data	long
<new>				

Figure 9 Configuring the Watch Window for) fixed point devices

20. Click on the Continuous Refresh button  in the watch window. This enables the window to run with real-time mode. By clicking the down arrow in this watch window, you may select "Customize Continuous Refresh Interval" and edit the refresh rate of the watch window. Note that choosing too fast an interval may affect performance.
21. The datalog buffers point to different system variables depending on the build level. They provide a means to visually inspect the variables and judge system performance. Open and setup time graph windows to plot the data log buffers as shown below. Alternatively, the user can import graph configurations files in the project folder; however, these files are not supported by all CCS4 versions. In order to import them, Click: Tools -> Graph -> DualTime... and select import and browse to the following location controlSUITE\development_kits\DRV830x-HC-C2-KITv*.*\<project directory> and select Graph1.graphProp, the Graph Properties window should now look like the Figure 10. Hit OK, this should add the Graphs to your debug perspective. Click on Continuous Refresh button  on the top left corner of the graph tab.

Note: If a second graph window is used, you could import Graph2.prop, the start Addresses for this should be DLOG_4CH_buff3 and DLOG_4CH_buff4.

Note: The default dlog.prescaler is set to 5 which will allow the dlog function to only log one out of every five samples.






Figure 10 Graph window settings

Run the Code

22. Run the code by pressing Run Button  in the Debug Tab.
23. The project should now run, and the values in the graphs and watch window should keep on updating. Below are some screen captures of typical CCS perspective while using this project, You may want to resize the windows according to your preference.
24. Once complete, reset the processor  (Target->Reset->Reset CPU) and then terminate the debug session by clicking  (Target->Terminate All). This will halt the program and disconnect Code Composer from the MCU.



Next Steps

25. It is not necessary to terminate the debug session each time the user changes or runs the code again. Instead the following procedure can be followed. After rebuilding the project, (Target->Reset->Reset CPU) , (Target->Reset->Restart) , and enable realtime options. Once complete, disable realtime options, and reset CPU. Terminate the project if the target device or the configuration is changed (Ram to Flash or Flash to Ram), and before shutting down CCS.
26. Customize the project to meet your motor. Change the motor parameters which can be found in [motorproject].h. Feel free to also change the PWM switching frequency (ISR frequency) and the base Q-value to balance accuracy and CPU bandwidth.
27. Now the user can open the lab manual found in : controlSUITE\development_kits\DRV830x-HC-C2-KITv*\[Project-Name]\~Docs and start experiments.

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, enhancements, improvements and other changes to its semiconductor products and services per JESD46, latest issue, and to discontinue any product or service per JESD48, latest issue. Buyers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All semiconductor products (also referred to herein as "components") are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its components to the specifications applicable at the time of sale, in accordance with the warranty in TI's terms and conditions of sale of semiconductor products. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by applicable law, testing of all parameters of each component is not necessarily performed.

TI assumes no liability for applications assistance or the design of Buyers' products. Buyers are responsible for their products and applications using TI components. To minimize the risks associated with Buyers' products and applications, Buyers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any patent right, copyright, mask work right, or other intellectual property right relating to any combination, machine, or process in which TI components or services are used. Information published by TI regarding third-party products or services does not constitute a license to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of significant portions of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI components or services with statements different from or beyond the parameters stated by TI for that component or service voids all express and any implied warranties for the associated TI component or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

Buyer acknowledges and agrees that it is solely responsible for compliance with all legal, regulatory and safety-related requirements concerning its products, and any use of TI components in its applications, notwithstanding any applications-related information or support that may be provided by TI. Buyer represents and agrees that it has all the necessary expertise to create and implement safeguards which anticipate dangerous consequences of failures, monitor failures and their consequences, lessen the likelihood of failures that might cause harm and take appropriate remedial actions. Buyer will fully indemnify TI and its representatives against any damages arising out of the use of any TI components in safety-critical applications.

In some cases, TI components may be promoted specifically to facilitate safety-related applications. With such components, TI's goal is to help enable customers to design and create their own end-product solutions that meet applicable functional safety standards and requirements. Nonetheless, such components are subject to these terms.

No TI components are authorized for use in FDA Class III (or similar life-critical medical equipment) unless authorized officers of the parties have executed a special agreement specifically governing such use.

Only those TI components which TI has specifically designated as military grade or "enhanced plastic" are designed and intended for use in military/aerospace applications or environments. Buyer acknowledges and agrees that any military or aerospace use of TI components which have **not** been so designated is solely at the Buyer's risk, and that Buyer is solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI has specifically designated certain components as meeting ISO/TS16949 requirements, mainly for automotive use. In any case of use of non-designated products, TI will not be responsible for any failure to meet ISO/TS16949.

Products

Audio	www.ti.com/audio
Amplifiers	amplifier.ti.com
Data Converters	dataconverter.ti.com
DLP® Products	www.dlp.com
DSP	dsp.ti.com
Clocks and Timers	www.ti.com/clocks
Interface	interface.ti.com
Logic	logic.ti.com
Power Mgmt	power.ti.com
Microcontrollers	microcontroller.ti.com
RFID	www.ti-rfid.com
OMAP Applications Processors	www.ti.com/omap
Wireless Connectivity	www.ti.com/wirelessconnectivity

Applications

Automotive and Transportation	www.ti.com/automotive
Communications and Telecom	www.ti.com/communications
Computers and Peripherals	www.ti.com/computers
Consumer Electronics	www.ti.com/consumer-apps
Energy and Lighting	www.ti.com/energy
Industrial	www.ti.com/industrial
Medical	www.ti.com/medical
Security	www.ti.com/security
Space, Avionics and Defense	www.ti.com/space-avionics-defense
Video and Imaging	www.ti.com/video

TI E2E Community

e2e.ti.com