


8 7 6 5 4 3 2 1

ALL NOTES ARE APPLICABLE UNLESS OTHERWISE SPECIFIED.

1. REFER TO ODB++ FILE FOR SPECIFIC COMPONENT LOCATION INFORMATION.
2. REMOVE THE METAL TAB ON BOTH BANANA JACKS BEFORE MOUNTING ON THE BOARD. USE LOCTITE THREADLOCKER BLUE 242 (OR EQUIVALENT) WHEN INSTALLING THE BANANA JACKS.
3. ROHS COMPLIANT AND LEAD FREE ASSEMBLY. USE WATER SOLUBLE FLUX DURING BOARD ASSEMBLY.
4. USE WATER SOLUBLE FLUX DURING BOARD ASSEMBLY.
5. MOUNT THE RF FENCE ON THE TOP OF THE PCB AFTER BOARD ASSEMBLY. SOLDER THE FENCE DOWN TO THE BOARD AROUND THE EDGES. NO GAPS. PLACE THE RF COVER ON THE FENCE.

REVISIONS			
ZONE	LTR	DESCRIPTION	DATE



SEE NOTE 5

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES TOLERANCES ARE: FRACTIONS DECIMALS ANGLES +/- .XX +/- .01 +/- .XXX +/- .005 +/-	CONTRACT NO.		TEXAS INSTRUMENTS INC.	
	APPROVALS	DATE	ASSEMBLY DRAWING TSW3085 EVM	
DRAWN	JOE CANTRELL 07-20-11	SIZE CODE IDENT NO DRAWING NO. REV.		
MATERIAL	ENGR	J. SETON	B	B
FINISH	DO NOT SCALE DRAWING		SCALE NONE	SHEET 1 OF 1

8 7 6 5 4 3 2 1