TMS320TCI6487/8 Semaphore

User's Guide

Literature Number: SPRUEF6C December 2006–Revised February 2008



ace			. 5
Modul	e Overvie	₩	. 6
1.1	Introduc	tion	. 6
1.2	Semaph	ore Architecture	. 6
Semap	ohore Op	eration	. 8
2.1	Semaph	ore Access Modes	. 8
2.2	Interrupt	Handling	. 8
2.3	Error Ha	Indling	. 9
2.4	Status C	luery	. 9
2.5	Releasir	ng Semaphore Resources	. 9
Emula	tion Con	siderations	. 9
Semap	ohore Usa	age Examples	10
4.1	CSL AP	I Calls	10
4.2	Accessir	ng Semaphore Resource When Free	12
4.3	Accessir	ng Semaphore Resource When Not Free	13
4.4	Accessir	ng Semaphore Resource in Combined Mode	14
Semap	ohore Reg	gisters	15
5.1	Register	Memory Map	15
5.2	Register	Descriptions	16
	5.2.1	Peripheral ID Register (PID)	16
	5.2.2	End-of-Interrupt Register (EOI)	16
	5.2.3	Direct Register (DIRECTx)	17
	5.2.4	Indirect Register (INDIRECTx)	18
	5.2.5	Query Register (QUERYx)	19
	5.2.6	Flag Register (FLAGx)	
	5.2.7	Flag Set Register (FLAG_SETx)	
	5.2.8	Error Register (ERR)	21
	5.2.9	Error Clear Register (ERROR_CLR)	22
	Modul 1.1 1.2 Semag 2.1 2.2 2.3 2.4 2.5 Emula Semag 4.1 4.2 4.3 4.4 Semag 5.1	Module Overvie1.1Introduc1.2SemaphSemaphore Op2.1Semaph2.2Interrupt2.3Error Ha2.4Status O2.5ReleasinEmulation ConsSemaphore Usa4.1CSL AP4.2Accessin4.3Accessin4.4Accessin5.1Register5.2Register5.2S.2.15.2.35.2.45.2.55.2.65.2.65.2.75.2.8	1.2 Semaphore Architecture Semaphore Operation

List of Figures

1	TMS320TCI6487/8 Semaphore Block Diagram	. 7
2	Peripheral ID Register (PID)	16
3	End-of-Interrupt Register (EOI)	16
4	Direct Register (DIRECTx)	17
5	Indirect Register (INDIRECTx)	18
6	Query Register (QUERYx)	19
7	Flag Register (FLAGx)	20
8	Flag Set Register (FLAG_SETx)	20
9	Error Register (ERR)	21
10	Error Clear Register (ERROR_CLR)	22

List of Tables

1	Register Memory Map	15
2	Peripheral ID Register (PID) Field Descriptions	16
3	End-of-Interrupt Register (EOI) Field Descriptions	16
4	Direct Register (DIRECTx) Field Descriptions	17
5	Indirect Register (INDIRECTx) Field Descriptions	18
6	Query Register (QUERYx) Field Descriptions	19
7	Flag Register (FLAGx) Field Descriptions	20
8	Flag Set Register (FLAG_SETx) Field Descriptions	20
9	Error Register (ERR) Field Descriptions	21
10	Error Register (ERROR_CLR) Field Descriptions	22



Preface SPRUEF6C–December 2006–Revised February 2008

Read This First

About This Manual

The TMS320TCI6487/8 semaphore module is used to support atomic arbitration among multiple CPUs for shared resources/peripherals. This document describes the usage of the semaphore and some of the CSL calls used to configure/use semaphore module.

Terms and Abbreviations

CPU— Central Processing Unit of the C64x+ Core

DSP— Digital Signal Processor

CSL— Chip Support Library

API— Application Programmer Interface

Trademarks

All trademarks are the property of their respective owners.



TMS320TCI6487/8 Semaphore

1 Module Overview

1.1 Introduction

In the TMS320TCI6487/8 device, multiple CPUs attempt to access shared resources simultaneously. To avoid resource conflict, the semaphore module is used to access shared resources in mutual exclusion. Unlike the software flag checking mechanism, the semaphore module is atomic, to satisfy the read-modify-write operation successfully.

The semaphore module allows acquisition of a semaphore resource/peripheral through read operations and also by posting a write request.

The number of resources the semaphore can handle is parameterized and, for theTMS320TCI6487/8 device, the following parameters are pre-programmed:

- NUM_SEM: Number of semaphore resources. In the device, the value is 32.
- QUEUE_DEPTH: Number of entries in each request queue. In the device, the value is 2.

1.2 Semaphore Architecture

The semaphore module has unique interrupts for each of the DSP cores (masters) to identify when that master has acquired the requested resource. Likewise, there are unique error interrupts to each DSP core when a particular master attempts to access the semaphore resource that is already locked by the same/other master. For each semaphore peripheral there are three different registers associated with it to acquire the resource: direct, indirect, or combined mechanism.

Semaphore resources are not directly connected within the module. Through software programming hardware resources can be allocated to any of the semaphore resources. Figure 1 shows the basic building blocks of semaphore module.

In Figure 1, *m* is the number of semaphore resources (i.e., 32) and *n* is the number of the master (i.e., 3). There are three 32-bits registers associated with each semaphore resource: DIRECT, INDIRECT, and QUERY registers. For each DSP core there is a FLAG register to notify the status of all 32 semaphore resources. The ERR register shows the different types of errors and the semaphore peripheral ID and master ID that caused the specific error. Upon receiving the error or interrupt event, the DSP core clears the particular bit field of the FLAG register by programming the FLAG register and writing to the semaphore end-of-interrupt (EOI) register to re-arm or re-enable a particular master's error/interrupt line.






Figure 1. TMS320TCI6487/8 Semaphore Block Diagram



2 Semaphore Operation

Any of the DSP cores can use the shared semaphore resources.

2.1 Semaphore Access Modes

Any semaphore resource can be accessed by three different modes:

• Direct Mode

In direct access mode, a resource is accessed by reading the DIRECTx (x is the semaphore peripheral number) register. Since there is no physical connection between the semaphore resources and the registers, any register can be mapped to any resource by software programming.

If the resource is free, access is immediately granted to the requested core. The FREE bit of the DIRECTx register is set to 1 signifying that the resource is free and access is granted to the requested core. The OWNER field of the DIRECTx register is set to the requested core ID.

If the resource is not available, no further action is taken by the semaphore module. The FREE bit of the DIRECTx register is set to 0 signifying that the resource is in use and the requested master should start a fresh request. In any case, there is no interrupt issued and there is no specific bit field set in the FLAGy (y is the granted core ID) register.

• Indirect Mode

In indirect access mode, a resource is accessed by writing to the DIRECTx, INDIRECTx, or QUERYx (x is the semaphore peripheral number) register. Since there is no physical connection between the semaphore resources and the registers, any register can be mapped to any resource by software programming.

If the resource is free, access is immediately granted to the requested core. The FREE bit of the DIRECTx, INDIRECTx, or QUERYx register is set to 1 signifying that the resource is free and acces is granted to the requested core. The OWNER field of the DIRECTx, INDIRECTx, or QUERYx register is set to the requested core ID. An interrupt is immediately issued to the requested core.

If the resource is not available, the request is added to the request queue assigned to the semaphore resource. When the resource becomes free, an interrupt is issued and the FREE bit of the DIRECTx, INDIRECTx, or QUERYx register is set to 1 signifying that access is now granted to the requested core. An interrupt is issued in this case. The specific bit field for the semaphore resource of the FLAGy (y is the granted core ID) register is set.

Combined Mode

In combined access mode, a resource is accessed by reading the INDIRECTx (x is the semaphore peripheral number) register. Since there is no physical connection between the semaphore resources and the registers, any register can be mapped to any resource by software programming.

If the resource is free, access is immediately granted to the requested core. The FREE bit of the INDIRECTx register is set to 1 signifying that the resource is free and access is granted to the requested core. The OWNER field of the INDIRECTx register is set to the requested core ID. No grant interrupt or flag register settings happen in this case.

If the resource is not available, the request is added to the request queue assigned to the semaphore resource. When the resource becomes free, an interrupt is issued and the FREE bit of the INDIRECTx register is set to 1 signifying that access is now granted to the requested core. An interrupt is issued in this case. The specific bit field for the semaphore resource of the FLAGy (y is the granted core ID) register is set.

2.2 Interrupt Handling

The first interrupt occurs when the pending queued request is serviced. To ensure that a re-arm of the master's interrupt occurs prior to the next access by the same or other resource, the master should:

- read the FLAGx (x is the particular master id) register
- clear the flag bit by programming the specific bit field for the semaphore resource of the FLAGx register
- write to the EOI register.



2.3 Error Handling

The first error interrupt occurs when there is a semaphore access error. To ensure that a re-arm of the master's error interrupt occurs prior to the next access violation, the master should:

- read the ERR register to determine the error type
- clear the error by programming the ERR_CLEAR register
- write to the EOI register.

2.4 Status Query

Before acquiring any semaphore resource, the requested core checks the availability of the resource by reading the QUERYx (x is the semaphore peripheral number) register. The FREE bit signifies whether a particular resource is free or not; when FREE=0 the resource is not free, when FREE=1 the resource is free. The OWNER field has a master ID that currently holds the resource (when FREE=0) or shows 0x00 (when FREE=1). Before taking any action on a resource, check the resource status.

2.5 Releasing Semaphore Resources

When the master that is granted access is finished with the shared resource, it must free the resource so that another master can access it. Writing 1 to the FREE bit of the DIRECTx, INDIRECTx, or QUERYx register releases the specific resource.

3 Emulation Considerations

During debug, when using the emulator, the CPU(s) may be halted. During emulation halt, the debugger reads to certain semaphore registers is ignored to avoid changing semaphore state. In other words, the debugger read of semaphore registers (DIRECTx, INDIRECTx) does not change the state of the semaphore peripheral. But, during emulation halt, the debugger checks the semaphore peripheral status via the QUERYx register.



4 Semaphore Usage Examples

This section provides some of the API call lists and examples to access semaphore resources.

4.1 CSL API Calls

This section provides the basic usage of the semaphore module using different CSL API calls. Three typical modes of accessing peripherals are illustrated with examples. Example 1 shows some of the API call lists.

Example 1. Sample API Call Lists

```
#define HW_SEM_RELEASE
                                 1
#define HW_SEM_REQUEST
                                 0
/********************/
   ENUMERATIONS */
/*
/********************
typedef enum {
   CSL\_SEM\_ID0 = 0,
    CSL\_SEM\_ID1 = 1,
    CSL\_SEM\_ID2 = 2,
}CSL_SemOwnerId;
typedef enum {
   CSL\_SEM\_ERR0 = 0,
   CSL\_SEM\_ERR1 = 1,
    CSL\_SEM\_ERR2 = 2,
    CSL SEM ERR3 = 3,
   CSL\_SEM\_ERR4 = 4
}CSL_SemError;
typedef enum {
   CSL_SEM_NOTFREE = 0,
                         /* Semaphore is not available */
/* Semaphore is available */
   CSL_SEM_FREE = 1
}CSL_SemFlag;
typedef enum {
   CSL_SEM_REARM_SEMINTO = 0,
   CSL_SEM_REARM_SEMINT1 = 1,
   CSL_SEM_REARM_SEMINT2 = 2,
   CSL\_SEM\_REARM\_SEMINT\_ALL = 0x10
}CSL_SemEOISet
typedef enum {
   CSL_SEM_QUERY_REVISION,
   CSL_SEM_QUERY_ERROR,
   CSL_SEM_QUERY_FLAGS,
   CSL_SEM_QUERY_STATUS,
   CSL_SEM_QUERY_DIRECT,
   CSL SEM OUERY INDIRECT
}CSL_SemHwStatusQuery;
```

Example 1. Sample API Call Lists (continued)

```
typedef enum {
   CSL_SEM_CMD_EOI_WRITE,
   CSL_SEM_CMD_FLAG_SET,
   CSL_SEM_CMD_FREE_DIRECT,
   CSL_SEM_CMD_WRITE_POST_DIRECT,
   CSL_SEM_CMD_FREE_INDIRECT,
   CSL_SEM_CMD_WRITE_POST_INDIRECT,
   CSL_SEM_CMD_FREE_QUERY,
   CSL_SEM_CMD_WRITE_POST_QUERY,
   CSL_SEM_CMD_CLEAR_ERR,
   CSL_SEM_CMD_CLEAR_FLAGS
}CSL_SemHwControlCmd;
·
/******************/
/* DATA STRUCTURES */
/********************/
typedef struct _CSL_SemFlagClear_Arg{
  CSL_BitMask32 mask;
CSL_SemOwnerId masterId;
}CSL_SemFlagSetClear_Arg;
typedef struct {
   CSL_SemRegsOvly regs;
} CSL_SemBaseAddress;
typedef struct {
  CSL_BitMask16 flags;
} CSL_SemParam;
typedef struct {
  Uint16 contextInfo;
} CSL_SemContext;
typedef struct CSL_SemObj{
  CSL_InstNum instNum;
   int
                   semNum;
   CSL_SemRegsOvly regs;
}CSL_SemObj;
typedef volatile CSL_SemObj *CSL_SemHandle;
typedef struct {
   int
                    semNum;
   CSL_SemOwnerId semOwner;
   CSL_SemFlag semFree;
} CSL_SemVal;
typedef struct CSL_SemFaultStatus {
        semNum;
   int
   CSL_SemError errorMask;
Uint16 faultID;
}CSL_SemFaultStatus;
```



Semaphore Usage Examples

4.2 Accessing Semaphore Resource When Free

A CPU accesses a shared peripheral (semaphore resource) by reading the semaphore direct (DIRECTx) register when the resource is free to use. Checking the semaphore query (QUERYx) register is the way to verify whether a particular resource is free or still in use by other CPU. If the FREE bit of QUERYx (where x is the semaphore peripheral ID) register is 1, the requested CPU directly locks the peripheral by reading the DIRECTx register and the requested peripheral is immediately granted access. After finishing the access, the CPU must release the resource by writing 1 to the FREE bit of the DIRECTx register so that another CPU can access the same resource.

Example 2 shows a semaphore resource (NUM = 4) acquired using the direct-read mode.

Example 2. Sample Code to Access Semaphore in Direct-Read Mode

```
CSL_SemVal
                      query;
       CSL_SemHandle mySemHandle;
       CSL_SemObj mySemObj;
       CSL_SemContext SemContext;
       CSL_SemParam mySemParam;
       mySemParam.flags = 4;
       CSL_semInit(&SemContext);
       mySemHandle = CSL_semOpen(&mySemObj, 0,&mySemParam, NULL);
       if(mySemHandle != NULL) {
          CSL_semGetHwStatus(mySemHandle,CSL_SEM_QUERY_STATUS,&query);
       -}
       if(query.semFree == CSL_SEM_FREE) {
          CSL_semGetHwStatus(mySemHandle, CSL_SEM_QUERY_DIRECT,&query);
       CSL_semGetHwStatus(mySemHandle,CSL_SEM_QUERY_STATUS,&query);
       if (query.semFree != CSL_SEM_FREE) {
         // Do peripheral access
       else {
            // return error.
       CSL_semHwControl(mySemHandle, CSL_SEM_CMD_FREE_DIRECT,NULL);
/* END Of Main code */
```

4.3 Accessing Semaphore Resource When Not Free

In certain situations when a shared resource is in use by another master, the requesting master/CPU can still post a request indirectly so that when the resource becomes available the requested master/CPU gets the access. Writing to the semaphore indirect (INDIRECTx) register when the resource is not free is the way to post a request in the request queue for the particular semaphore peripheral. Checking the semaphore query (QUERYx) register is the way to verify whether a particular resource is free or still in use by other CPU. If the FREE bit of the QUERYx (where x is the semaphore peripheral ID) register is 0 (indicating resource is in use), then the requested CPU can post a request by writing to the INDIRECTx register. When the resource becomes free, the master is notified by the interrupt and the requested peripheral is granted access. After finishing the access the CPU must release the resource by writing 1 to the FREE bit of the INDIRECTx register so that another CPU can access the same resource.

Example 3 shows a semaphore resource (NUM = 22) acquired using indirect-write mode.

Example 3. Sample Code to Access Semaphore in Indirect-Write Mode

```
CSL_SemVal
                query;
CSL_SemHandle mySemHandle;
CSL SemObi
               mySemObi;
 CSL_SemContext SemContext;
CSL_SemParam
              mySemParam;
mySemParam.flags = 22;
CSL_semInit(&SemContext);
mySemHandle = CSL_semOpen(&mySemObj, 0,&mySemParam, NULL);
 if(mySemHandle != NULL) {
    CSL_semGetHwStatus(mySemHandle,CSL_SEM_QUERY_STATUS,&query);
 if(query.semFree == CSL_SEM_FREE) {
   // Direct access
  CSL_semGetHwStatus(mySemHandle,CSL_SEM_QUERY_DIRECT,&query);
 CSL_semGetHwStatus(mySemHandle,CSL_SEM_QUERY_STATUS,&query);
 if (query.semFree != CSL_SEM_FREE) {
   // Indirect access
   CSL_semHwControl(mySemHandle, CSL_SEM_CMD_WRITE_POST_INDIRECT,NULL);
    // Release the previously locked semaphore
  CSL_semHwControl(mySemHandle, CSL_SEM_CMD_FREE_DIRECT,NULL);
 }
// Get the semaphore status.Still lock. This time for indirect pending access
CSL_semGetHwStatus(mySemHandle,CSL_SEM_QUERY_STATUS,&query);
if (query.semFree != CSL_SEM_FREE) {
   // do semaphore access
else {
    // Return error
 CSL_semHwControl(mySemHandle, CSL_SEM_CMD_FREE_INDIRECT,NULL);
 /* END Of Main code */
```



Semaphore Usage Examples

4.4 Accessing Semaphore Resource in Combined Mode

A semaphore resource can be accessed in combination of direct-read mode and indirect-write mode. When the resource is free, access is immediately granted and when the resource is not free, it posts a request in the request queue.

Example 4 shows a semaphore resource (NUM = 0) acquired using combined-access mode.

Example 4. Sample Code to Access Semaphore in Combined-Access Mode

```
CSL_SemVal
                       query;
        CSL_SemHandle mySemHandle;
       CSL_SemObj
                    mySemObj;
        CSL_SemContext SemContext;
       CSL_SemParam mySemParam;
       mySemParam.flags = 0;
       CSL_semInit(&SemContext);
       mySemHandle = CSL_semOpen(&mySemObj, 0,&mySemParam, NULL);
        if(mySemHandle != NULL) {
          CSL_semGetHwStatus(mySemHandle,CSL_SEM_QUERY_STATUS,&query);
        }
       if(query.semFree == CSL_SEM_FREE) {
           CSL_semGetHwStatus(mySemHandle, CSL_SEM_QUERY_INDIRECT, &query);
        CSL_semGetHwStatus(mySemHandle,CSL_SEM_QUERY_STATUS,&query);
        if (query.semFree != CSL_SEM_FREE) {
          // Do peripheral access
        else {
     // return error.
        }
       CSL_semHwControl(mySemHandle, CSL_SEM_CMD_FREE_QUERY,NULL);
/* END Of Main code */
```



5 Semaphore Registers

This section provides the semaphore memory map and descriptions of the peripheral registers.

5.1 Register Memory Map

Offset	Register	Description	See
0x000	PID	Peripheral Revision ID Register	Section 5.2.1
0x00C	EOI	EOI Register	Section 5.2.2
0x100 - 0x17C	DIRECT0-31	Direct Registers 0-31	Section 5.2.3
0x200 - 0x27C	INDIRECT0-31	Indirect Registers 0-31	Section 5.2.4
0x300 - 0x37C	QUERY0-31	Query Registers 0-31	Section 5.2.5
0x400	FLAG0	Flag0 Register (for C64x+ Core0)	Section 5.2.6
0x404	FLAG1	Flag1 Register (for C64x+ Core1)	Section 5.2.6
0x408	FLAG2	Flag2 Register (for C64x+ Core2)	Section 5.2.6
0x480	FLAG_SET0	Flag Set0 Register (for C64x+ Core0)	Section 5.2.7
0x484	FLAG_SET1	Flag Set1 Register (for C64x+ Core1)	Section 5.2.7
0x488	FLAG_SET2	Flag Set2 Register (for C64x+ Core2)	Section 5.2.7
0x500	ERR	Error Register	Section 5.2.8
0x504	ERROR_CLR	Error Clear Register	Section 5.2.9

Table 1. Register Memory Map

5.2 Register Descriptions

The following are some sample semaphore peripheral registers.

5.2.1 Peripheral ID Register (PID)

The semaphore peripheral ID (PID) register is shown in Figure 2 and described in Table 2.

Figure 2. Peripheral ID Register (PID)

31 30	29 28	27							16
SCHEME	Reserved					FU	NC		
R-0x1	R-0x					R-0:	x802		
15		11	10	8	7	6	5		0
	RTL		MAJO	OR	CUS	ТОМ		MINOR	
	R-0x0		R-0>	(1	R-0)x0		R-0x0	

LEGEND: R/W = Read/Write; R = Read only; -n = value after reset


Table 2. Peripheral ID Register (PID) Field Descriptions

Bit	Field	Value	Description
31-30	SCHEME	01b	Used to distinguish which ID scheme is used.
29-28	RSVD	00	Reserved. Read returns 0. Write has no effect.
27-16	FUNC	0x802	Specifies module family
15-11	RTL	0000b	RTL Version
10-8	MAJOR	01b	Major Revision
7-6	CUSTOM	00b	Special/Custom Revision
5-0	MINOR	000000b	Minor Revision

5.2.2 End-of-Interrupt Register (EOI)

The semaphore end-of-interrupt (EOI) register is used for re-arming the error/interrupt line after serving the existing error/interrupt. The EOI register is shown in Figure 3 and described in Table 3.

Figure 3. End-of-Interrupt Register (EOI)



LEGEND: W = Write only; -n = value after reset

Table 3. End-of-Interrupt Register (EOI) Field Descriptions⁽¹⁾

Bit	Field	Value	Description
31-8	Reserved		Reserved, Write has no effect
7-0	7-0 INTERRUPT/ERROR SELECT 0x0 0x0		Selection of particular Error/Interrupt line to re-arm.
			Re-enable semint0 (For C64x+ Core0)
			Re-enable semint1 (For C64x+ Core1)
		0x02	Re-enable semint2 (For C64x+ Core2)
		0x10	Re-enable All Error interrupt (For all C64x+ Cores)

⁽¹⁾ Reading of the EOI register will result in a memory-read exception being generated.

5.2.3 Direct Register (DIRECTx)

The semaphore direct (DIRECTx) register acquires the semaphore resource in direct-read mode as well as indirect-write mode. If the resource is free, the FREE field of the DIRECTx (x is the semaphore peripheral ID being requested) signifies whether the resource is granted or not. The DIRECTx register is shown in Figure 4 and described in Table 4.

Figure 4. Direct Register (DIRECTx)

31						16	
		Rese	erved				
	R-0x0000						
15		8	7		1	0	
	OWNER			Reserved		FREE	
	R-0x00			R-0x00		R/W- 0x1	

LEGEND: R/W = Read/Write; R = Read only; -n = value after reset

Bit	Field	Value	Description
31-16	Reserved	0x0000	Reserved. Read returns 0. Write has no effect.
15-8	OWNER	0x00	When FREE = 0: Semaphore resource owner ID When FREE = 1: The value returns 0x00
7-1	Reserved	0x00	Reserved. Read returns 0. Write has no effect.
0	FREE		Read Operation:
		0	Semaphore is not granted.
		1	Semaphore is granted to the Master. FREE is cleared by the hardware at the end of the access.
			Write Operation:
		0	Request is posted in the queue (indirect mode).
		1	Semaphore is freed.

Table 4. Direct Register (DIRECTx) Field Descriptions



5.2.4 Indirect Register (INDIRECTx)

The semaphore indirect (INDIRECTx) register acquires the semaphore resource in indirect-write mode. If the resource is free, the FREE bit of the INDIRECTx (x is the semaphore peripheral ID being requested) signifies whether the resource is granted or not. In addition, an interrupt is sent to the requested master. The INDIRECT register is shown in Figure 5 and described in Table 5.

Figure 5. Indirect Register (INDIRECTx)

31						16
		Rese	erved			
	R-0x0000					
15		8	7		1	0
	OWNER			Reserved		FREE
	R-0x00			R-0x00		R/W- 0x1

LEGEND: R/W = Read/Write; R = Read only; -*n* = value after reset

Table 5. Indirect Register (INDIRECTx) Field Descriptions

Bit	Field	Value	Description
31-16	Reserved	0x0000	Reserved. Read returns 0. Write has no effect.
15-8	OWNER	0x00	When FREE = 0: Semaphore resource owner ID When FREE = 1: The value returns 0x00
7-1	Reserved	0x00	Reserved. Read returns 0. Write has no effect.
0	FREE		Read Operation:
		0	Semaphore is not granted.
		1	Semaphore is granted to the Master. FREE is cleared by the hardware at the end of the access.
			Write Operation:
		0	Request is posted in the queue (indirect mode).
		1	Semaphore is freed.

5.2.5 Query Register (QUERYx)

Each semaphore query register (QUERYx) checks the current semaphore resource status and also can be used for indirect-write mode to access the particular resource. Reading the QUERYx (x is the semaphore peripheral ID being accessed) register does not affect the status of the particular peripheral. The QUERY register is shown in Figure 6 and described in Table 6.

Figure 6. Query Register (QUERYx)

31						16
		Rese	erved			
	R-0x0000					
15		8	7		1	0
	OWNER			Reserved		FREE
	R-0x00			R-0x00		R/W- 0x1

LEGEND: R/W = Read/Write; R = Read only; -*n* = value after reset

Table 6. Query Register (QUERYx) Field Descriptions

Bit	Field	Value	Description
31-16	Reserved	0x0000	Reserved. Read returns 0. Write has no effect.
15-8	OWNER	0x00	When FREE = 0: Semaphore resource owner ID When FREE = 1: The value returns 0x00
7-1	Reserved	0x00	Reserved. Read returns 0. Write has no effect.
0	FREE		Read Operation:
		0	Semaphore is not granted
		1	Semaphore is not granted to the Master
			Write Operation:
		0	Request is posted in the queue (indirect mode)
		1	Semaphore is freed

5.2.6 Flag Register (FLAGx)

Each semaphore flag (FLAGx, where x is the Master ID) register checks whether the particular master/core is currently holding the semaphore resource or not. There is one register for each core and the particular bit field signifies the holding status of the particular semaphore peripheral by the requested master. Once access to the particular semaphore resource is complete, the corresponding flag bit is cleared by writing a 1 to the particular bit of the FLAG register. The FLAGx register is shown in Figure 7 and described in Table 7.

Figure 7. Flag Register (FLAGx)

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
F31	F30	F29	F28	F27	F26	F25	F24	F23	F22	F21	F20	F19	F18	F17	F16
	R-0x0000														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
F15	F14	F13	F12	F11	F10	F9	F8	F7	F6	F5	F4	F3	F2	F1	F0
	R-0x0000														

LEGEND: R/W = Read/Write; R = Read only; -n = value after reset

Table 7. Flag Register (FLAGx) Field Descriptions

Bit	Field	Value	Description
31-0	Fy		Semaphore Flag Value
		0x0	Semaphore resource y is not owned by the master x
		0x1	Semaphore resource y is owned by the master x

5.2.7 Flag Set Register (FLAG_SETx)

Each semaphore flag set (FLAG_SETx, where x is the Master ID) register sets the flag bit of the particular semaphore peripheral. This register is implemented to check, by software programming, whether any resource can be accessed by the any of the masters. There is one register for each core and writing to the particular bit field sets the semaphore flag registers (FLAGx) corresponding bit-field value. The FLAG_SETx register is shown in Figure 8 and described in Table 8.

Figure 8. Flag Set Register (FLAG_SETx)

31	30	29	28	27	26	25	24	23	22	21	20	19	18	17	16
F31	F30	F29	F28	F27	F26	F25	F24	F23	F22	F21	F20	F19	F18	F17	F16
	W-0x0000														
15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
F15	F14	F13	F12	F11	F10	F9	F8	F7	F6	F5	F4	F3	F2	F1	F0
	W-0x0000														

LEGEND: R/W = Read/Write; R = Read only; -n = value after reset

Table 8. Flag Set Register (FLAG_SETx) Field Descriptions

Bit	Field	Value	Description
31-0	Fy		Semaphore Flag Set
		0x0	Do nothing
		0x1	Semaphore flag y is cleared

5.2.8 Error Register (ERR)

The semaphore error (ERR) register updates any kind of error that occurs while acquiring a semaphore resource by any core. By reading the ERR register the particular master/core should clear the particular error and program the EOI register so that a re-arm occurs for the next semaphore access by the same master. The ERR register is shown in Figure 9 and described in Table 9.

Figure 9. Error Register (ERR)

31							16
		Rese	erved				
		R-0x	0000				
15		8	7		3	2	0
	FAULTID			SEM_NUM		ERR	
	R-0x00			R-0x0		R-0x0	

LEGEND: R/W = Read/Write; R = Read only; -*n* = value after reset

Table 9. Error Register (ERR) Field Descriptions

Bit	Field	Value	Description
31-16	Reserved	0x0000	Reserved. Read returns 0. Write has no effect.
15-8	FAULTID	0x00	Master ID number that caused the error
7-3	SEM_NUM	0x00	Semaphore peripheral ID number (0 to 31)
2-0	ERR		Semaphore error code.
		000	No semaphore access error has occurred.
		001	Master ID FAULTID attempted to free semaphore NUM when it was already free.
		010	Master ID FAULTID attempted to free semaphore NUM while not currently owned by FAULTID.
		011	Master ID FAULTID attempted to acquire semaphore NUM while it was already owned by FAULTID.
		100	Master ID FAULTID attempted to acquire semaphore NUM while FAULTID already had a request pending.



5.2.9 Error Clear Register (ERROR_CLR)

The semaphore error clear (ERROR_CLR) register clears the existing error code. The master should reprogram the EOI register after clearing the error so that a re-arm occurs for the next error event. The ERROR_CLR register is shown in Figure 10 and described in Table 10.

Figure 10. Error Clear Register (ERROR_CLR)

31								16
		Rese	erved					
		R-0x	0000					
15		8	7		3	2		0
	FAULTID			SEM_NUM			ERR	
	R-0x00			R-0x0			R-0x0	

LEGEND: R/W = Read/Write; R = Read only; -n = value after reset

Table 10. Error Register (ERROR_CLR) Field Descriptions

Bit	Field	Value	Description
31-16	Reserved	0x0000	Reserved. Read returns 0. Write has no effect.
15-8	FAULTID	0x00	Master ID number that caused the error
7-3	SEM_NUM	0x00	Semaphore peripheral ID number (0 to 31)
2-0	ERR		Semaphore error code.
		000	No semaphore access error has occurred.
		001	Master ID FAULTID attempted to free semaphore NUM when it was already free.
		010	Master ID FAULTID attempted to free semaphore NUM while not currently owned by FAULTID.
		011	Master ID FAULTID attempted to acquire semaphore NUM while it was already owned by FAULTID.
		100	Master ID FAULTID attempted to acquire semaphore NUM while FAULTID already had a request pending.

IMPORTANT NOTICE

Texas Instruments Incorporated and its subsidiaries (TI) reserve the right to make corrections, modifications, enhancements, improvements, and other changes to its products and services at any time and to discontinue any product or service without notice. Customers should obtain the latest relevant information before placing orders and should verify that such information is current and complete. All products are sold subject to TI's terms and conditions of sale supplied at the time of order acknowledgment.

TI warrants performance of its hardware products to the specifications applicable at the time of sale in accordance with TI's standard warranty. Testing and other quality control techniques are used to the extent TI deems necessary to support this warranty. Except where mandated by government requirements, testing of all parameters of each product is not necessarily performed.

TI assumes no liability for applications assistance or customer product design. Customers are responsible for their products and applications using TI components. To minimize the risks associated with customer products and applications, customers should provide adequate design and operating safeguards.

TI does not warrant or represent that any license, either express or implied, is granted under any TI patent right, copyright, mask work right, or other TI intellectual property right relating to any combination, machine, or process in which TI products or services are used. Information published by TI regarding third-party products or services does not constitute a license from TI to use such products or services or a warranty or endorsement thereof. Use of such information may require a license from a third party under the patents or other intellectual property of the third party, or a license from TI under the patents or other intellectual property of TI.

Reproduction of TI information in TI data books or data sheets is permissible only if reproduction is without alteration and is accompanied by all associated warranties, conditions, limitations, and notices. Reproduction of this information with alteration is an unfair and deceptive business practice. TI is not responsible or liable for such altered documentation. Information of third parties may be subject to additional restrictions.

Resale of TI products or services with statements different from or beyond the parameters stated by TI for that product or service voids all express and any implied warranties for the associated TI product or service and is an unfair and deceptive business practice. TI is not responsible or liable for any such statements.

TI products are not authorized for use in safety-critical applications (such as life support) where a failure of the TI product would reasonably be expected to cause severe personal injury or death, unless officers of the parties have executed an agreement specifically governing such use. Buyers represent that they have all necessary expertise in the safety and regulatory ramifications of their applications, and acknowledge and agree that they are solely responsible for all legal, regulatory and safety-related requirements concerning their products and any use of TI products in such safety-critical applications, notwithstanding any applications-related information or support that may be provided by TI. Further, Buyers must fully indemnify TI and its representatives against any damages arising out of the use of TI products in such safety-critical applications.

TI products are neither designed nor intended for use in military/aerospace applications or environments unless the TI products are specifically designated by TI as military-grade or "enhanced plastic." Only products designated by TI as military-grade meet military specifications. Buyers acknowledge and agree that any such use of TI products which TI has not designated as military-grade is solely at the Buyer's risk, and that they are solely responsible for compliance with all legal and regulatory requirements in connection with such use.

TI products are neither designed nor intended for use in automotive applications or environments unless the specific TI products are designated by TI as compliant with ISO/TS 16949 requirements. Buyers acknowledge and agree that, if they use any non-designated products in automotive applications, TI will not be responsible for any failure to meet such requirements.

Following are URLs where you can obtain information on other Texas Instruments products and application solutions:

Products		Applications	
Amplifiers	amplifier.ti.com	Audio	www.ti.com/audio
Data Converters	dataconverter.ti.com	Automotive	www.ti.com/automotive
DSP	dsp.ti.com	Broadband	www.ti.com/broadband
Clocks and Timers	www.ti.com/clocks	Digital Control	www.ti.com/digitalcontrol
Interface	interface.ti.com	Medical	www.ti.com/medical
Logic	logic.ti.com	Military	www.ti.com/military
Power Mgmt	power.ti.com	Optical Networking	www.ti.com/opticalnetwork
Microcontrollers	microcontroller.ti.com	Security	www.ti.com/security
RFID	www.ti-rfid.com	Telephony	www.ti.com/telephony
RF/IF and ZigBee® Solutions	www.ti.com/lprf	Video & Imaging	www.ti.com/video
		Wireless	www.ti.com/wireless

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2008, Texas Instruments Incorporated