Technical Article Catch Your Breath: Which Is a Better Occupancy Detector – mmWave or PIR?



Keegan@TI

Let's start with what might be an all-too-familiar scenario. You find yourself working late and alone; maybe you're typing out some last emails for the evening or crunching some numbers for an upcoming deadline. Suddenly, the lights in your "smart office" turn off, and you find yourself standing up and waving your arms so that the motion sensor will trigger the lights back on.

Has this ever happened to you? Today's motion sensors are notoriously bad at detecting when indoor spaces are occupied and are often useless when a person is relatively still – such as working quietly in an office chair. The technologies in today's passive infrared (PIR) or ultrasonic motion sensors do not have the fidelity to detect finer motion, such as when someone is sitting still at their desk, typing, breathing or talking on the phone.



Figure 1. Today's Motion-sensing Technologies Such as PIR or Ultrasonic Can Fail to Detect Occupancy

Millimeter-wave (mmWave) radar is an excellent technology for occupancy sensing, as it has the ability to detect the kinds of very fine motion that might escape other sensing technologies. To prove this capability, the mmWave team ran an experiment in a conference room that contained a PIR motion sensor. We also set up an mmWave evaluation module (EVM) on a tripod pointing into a conference room such that the EVM's 120-degree field of view could see the entire room. Using the out-of-box demo, we configured the mmWave sensor for an indoor, low-motion scene by maximizing velocity resolution, ignoring static clutter and not grouping detected objects. As you can see from Figure 2, the conference room was about 6m in length and had a fair amount of static clutter in the scene, including a large table and several chairs.

1





Figure 2. The Conference Room Where We Compared the Motion-detection Performance of an mmWave EVM to a PIR Sensor; Nos. 1 through 7 Indicate the Different Chair Positions around the Conference Room Table

We tested three different categories of motion with the mmWave EVM and PIR motion sensor:

- Major motion (walking).
- Fine motion (typing).
- Very fine motion (breathing).

We tested all three motion types in locations spanning the entire conference room and found that the PIR sensor was able to detect walking across the entire conference room, but was unable to detect typing or breathing in any location. In contrast, as shown in Table 1, the mmWave sensor was able to detect typing and breathing as well as walking.

Figure 3 shows reflection points that represent motion detected by the mmWave sensor. This motion can even be detected in challenging environments, such as rooms filled with smoke as seen in Figure 4.

		Major Motion (Walking)		Fine Motion (Typing)		Very Fine Motion (Breathing)	
Distance from Sensor	Chair Location	mmWave	PIR	mmWave	PIR	mmWave	PIR
2.6m	4	Р	Р	Р	О	Р	0
2.7m	3	Р	Р	Р	0	Р	0
3.4m	2	Р	Р	Р	0	Р	0
3.6m	5	Р	Р	Р	0	Р	0
4.2m	1	Р	Р	Р	0	Р	0
4.2m	6	Р	Р	Р	0	Р	0
5.1m	7	Р	Р	Р	0	P*	0

Table 1. It Is Clear from the Table That mmWave Can Detect a Wide Range of Motions, While PIR WasOnly Able to Detect Major Motion Such as Walking

* Only deep breathing detected





Figure 3. Motion from mmWave Appears as Points in the Scatter Plot and Doppler-range Plot. Only Motion Is Displayed in These Plots When Static Clutter Is Removed.



Figure 4. mmWave Fine Motion Detection Can Function Even in Challenging Environments, Such as Rooms That Are Filled with Smoke and Sources of Heat.

provide range and angle information a factory robot that shuts down when a moving object comes into its range of motion

In this video, we put mmWave into action to illustrate a few people counting applications that can make buildings smarter.

Additional Resources

- Run the People Counting demo yourself!
- Check out the People Counting TI Design. (TIDEP-01000)
- See People Counting technology in action!



- Watch people tracking and motion detection using mmWave for building automation.
- Find resources and reference designs for people counting here.

IMPORTANT NOTICE AND DISCLAIMER

TI PROVIDES TECHNICAL AND RELIABILITY DATA (INCLUDING DATA SHEETS), DESIGN RESOURCES (INCLUDING REFERENCE DESIGNS), APPLICATION OR OTHER DESIGN ADVICE, WEB TOOLS, SAFETY INFORMATION, AND OTHER RESOURCES "AS IS" AND WITH ALL FAULTS, AND DISCLAIMS ALL WARRANTIES, EXPRESS AND IMPLIED, INCLUDING WITHOUT LIMITATION ANY IMPLIED WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OF THIRD PARTY INTELLECTUAL PROPERTY RIGHTS.

These resources are intended for skilled developers designing with TI products. You are solely responsible for (1) selecting the appropriate TI products for your application, (2) designing, validating and testing your application, and (3) ensuring your application meets applicable standards, and any other safety, security, regulatory or other requirements.

These resources are subject to change without notice. TI grants you permission to use these resources only for development of an application that uses the TI products described in the resource. Other reproduction and display of these resources is prohibited. No license is granted to any other TI intellectual property right or to any third party intellectual property right. TI disclaims responsibility for, and you will fully indemnify TI and its representatives against, any claims, damages, costs, losses, and liabilities arising out of your use of these resources.

TI's products are provided subject to TI's Terms of Sale or other applicable terms available either on ti.com or provided in conjunction with such TI products. TI's provision of these resources does not expand or otherwise alter TI's applicable warranties or warranty disclaimers for TI products.

TI objects to and rejects any additional or different terms you may have proposed.

Mailing Address: Texas Instruments, Post Office Box 655303, Dallas, Texas 75265 Copyright © 2023, Texas Instruments Incorporated